

Manual Web Coiler / Winch

key for rollshutter exploded diagram

- 1. Operator:** web or rope coiler with swivel mount
: flush mounted crank handle winch
- 2. Web Strap or Rope** - connects to pulley disc #4
- 3. Wall Guide** - for web strap or rope
- 4. Pulley Disc** - state box size
- 5. Cap for Pulley** - fits into 60 mm octagonal axle pipe
- 6. Bearing** - steel bearings w nylon bushings 28 mm
- 7. Octagonal Axle Pipe** - 60 mm in 0.6 or 0.9 (+ 3.5m) wall
- 8. Channel Guides** - two sizes - specify profile style
- 9. Endplate** - state size, color and side required
- 10. Back of Box** - one piece top and back - state size & color
- 11. Service Access Panel** - state size & color
- 12. Guide Rail** - state color & profile style - specify details
- 13. Cover Buttons** - pop into screwdriver access holes
- 14. Curtain** - state color and profile style
- 15. Endbar** - contains seal
- 16. Stoppers** - state size **16a. T Stoppers** - casement windows
- 17. Side Locks** - state profile style
- 18. Staple or Rivet** - to secure side lock into profile slat
- 19. Security Spring Hangers** - state box size and profile style

Please have color, style of profile and size of box available.